

Custom All-Rite Skylight Installation Instructions



1. Unpack the outer wrapping leaving the plastic film on the skylight to protect from scratches during installation
2. Place putty tape on the bottom edge of the skylight frame
3. Center skylight over the opening and install fasteners at each corner. Don't tighten all the way!
4. Continue installing the remainder of the fasteners along each side
5. When all the fasteners are installed, tighten each of them down in turn
6. Use caulking to seal every fastener so that there is no danger of leakage
7. Caulk all edges of the skylight where it contacts the roof
8. Peel protective plastic film off the skylight
9. To clean your skylight, use a soft non-abrasive cloth to wipe the inside and outside. Water or mild soap may also be used.

- Entry Doors
- Ladders

- Holding & Water Tanks
- Aluminum & Fiberglass Siding

- Windows
- Compartment Doors

1500 Shelton Drive
Hollister, CA 95023
(P) 831-636-9566
(F) 831-636-9464
sales@all-rite.com
www.all-rite.com



www.all-rite.com
ALL-RITE
Custom Manufacturing